



Glass & Hygiene Maintenance

Before placing glasses into the glasswasher you must manually remove lipstick and discard any drink residues into the sink.

Cabinet Glasswasher Operation

- Ensure that the machine is up to temperature
- Fill basket. **ONLY GLASSES! No coffee cups**
- Place in basket, close door and run cycle
- Check glasses at the end of the cycle

Is water running off glass as a clear sheet?	This is correct
Can you see droplets sticking to the surface?	This is incorrect and indicates there is a problem – see renovation

Daily Maintenance Procedure

- Switch off power
- Remove basket
- Drain machine
- Remove and clean filters
- Top up chemicals
- Leave door open overnight

Weekly Maintenance Procedure

- Remove wash arms
- Remove and clean jets and nozzles
- Reassemble
- Clean machine by running cycle with renovate
- Regenerate water softener (if fitted)

Renovation

- New glasses may be coated in lubricant used in glass manufacture
- To remove this, **RENOVATE ALL NEW GLASSES BEFORE USE.**
- Sugars, proteins, hop resins and detergent residues may gradually build up a film on the glass which may cause the beer foam to collapse – this can be prevented with **regular renovation** (at least every two months).

* ***Refer to C.O.S.H.H Data Sheets***

For more information or to book a service call contact Crystaltech on 0370 350 2424